


CEMENTED LINER ASSEMBLIES SETTING COLLARS

All Chancellor setting collars are typically run above the liner hanger for the purpose of carrying the liner weight and engagement of the setting tool while running-in the hole. They also serve as a tool entry guide after completion.

The Plain Liner top Adapter is the most efficient and economic means of running a liner where a seal or differential pressure rating is not required.

The Model A is a simple and economical choice for RH release. The model AR has splines which offer RH setting (or rotation) of liner in tension as well as RH release with the use of a rotating dog sub.



PLAIN LINER TOP
ADAPTER



MODEL A



MODEL AR